

# 1997-2006 JEEP TJ

## POD MOUNT LIGHT BRACKET INSTALLATION INSTRUCTIONS



## SAFETY

**Know safety, no injury. Know injury, no safety. ~Author Unknown**

If there are any questions, call 1-855-HHTOUGH

- **READ ALL SAFETY INSTRUCTIONS BEFORE INSTALLATION**
  - FOLLOW ALL INSTRUCTIONS FOR PROPER ASSEMBLY
  - WEAR APPROPRIATE EYE PROTECTION
  - EXERCISE CARE WHEN LIFTING COMPONENTS
  - USE APPROPRIATE TORQUE FOR BOLTS

### SUGGESTED TORQUE VALUES FOR STEEL GRADE SAE 5 BOLTS

BOLT DIAMETER (INCH)	TREADS PER INCH	TORQUE (POUND-FEET)
1/4	20	7
5/16	18	14
3/8	16	25
7/16	14	40
1/2	13	60
9/16	12	88
5/8	11	120
3/4	10	200
7/8	9	302
1	8	466



2007-2016 Jeep JK

### I. PARTS LIST

<u>QUANTITY</u>	<u>PART NUMBER</u>	<u>DESCRIPTION</u>	<u>CHECKOFF</u>
1	601-56-2322	LEFT TJ POD LIGHT MOUNT	
1	601-56-2323	RIGHT TJ POD LIGHT MOUNT	
4	319-12-0019	TORX 40 PAN HEAD BOLT	
1	601-56-2861	POD MOUNT FOAM RIGHT	
1	601-56-2860	POD MOUNT FOAM LEFT	

### II. TOOL LIST

1. Basic tool set
2. Torx 40 socket

### III. REMOVAL OF OEM BOLTS

1. Using a Torx 40 socket remove both the horizontal bolts from the A-Pillar



#### IV. INSTALATION OF A-PILLAR LIGHT BRACKET

1. Peel the cover off the back of the provided foam
2. Place the foam on the back of the POD MOUNT LIGHT BRACKETS.



3. Place the A-PILLAR LIGHT BRACKET onto the A-Pillar as shown
4. Using a Torx 40 socket use provided bolts to secure the POD MOUNT LIGHT BRACKET



5. Repeat for the other side
6. Install lights according to their instructions



2007-2016 Jeep JK



Congratulations! Your hammerhead A-PILLAR LIGHT BRACKETS installation is now complete.

Thank you for your purchase.